












Member of the Phoenix Contact Group







Mounting Tools

Assembling Tools for all Connectors in this Catalog








Mounting Tools

Picture	Description	Part Number
	Assembly tool for RC/UC-Connectors with an outside male thread. This tool holds the insert in place.	RC-Z2096
	Assembly tool for RC/UC-Connectors with female coupling nuts. This tool holds the insert in place.	RC-Z2099
	Assembly tool for panel mount connectors style A, right angled. To push the connector insert in place.	RC-Z2103
	For RC-panel connectors to push the snap ring and the insert into the housing. It can also be done with a screwdriver.	RC-Z2360
	Disassembly tool for the above 	RC-Z2290
	Removal tool for crimp contacts from the connecting side.	RC-Z2097
	Removal tool for crimp contacts from the mating side.	RC-Z2098
	Removal tool for crimp contacts from the connecting side.	RC-Z2220

Mounting Tools

Picture	Description	Part Number
	Removal tool for crimp contacts from the mating side.	RC-Z2274
	Removal tool for crimp contacts from the connecting side	RC-Z2219
	Removal tool for crimp contacts from the mating side	SC-Z2273
	Assembly tool for HC-connectors with outside thread	HC-Z2295
	Assembly tool for HC-connectors with coupling nut	HC-Z2294
	<p>Wrenches for tightening the Coninvers connector shells. Quality high performance thin head design.</p> <p>14 and 15 mm 16 and 17 mm 20 and 22 mm 22 and 24 mm 24 and 26 mm 30 and 32 mm</p>	<p>MS-1415 MS-1617 MS-2022 MS-2224 MS-2426 MS-3032</p>

Mounting Tools

Picture	Description	Part Number
	Torque screwdriver incl. sickle spanner for M23 connectors with coupling nut.	SF-Z0028
 <p>spare sickle</p>		SF-Z0027
	Removal tool for RF-panel connectors with connector inserts with snap ring locking.	RF-Z0001
	Removal tool for ST-panel connectors with connector inserts with snap ring locking.	ST-Z0001
	Contact insert and removal tool for RC-crimp contacts male and female with 1 mm Ø	RC-Z2494
	Contact insert and removal tool for RC-crimp contacts male and female with 2 mm Ø	RC-Z2490